

Accessories for Spring Plungers



2470.10.11
Insertion Tool
 for 2470.10.



2470.12.010.017
Insertion Tool
 for 2479. and 3479.



2472.11.003 up to 2472.11.020
Thrust pad driver
 for 2472.01./02.

Order No	for thread
2472.11.003	M 3
2472.11.004	M 4
2472.11.005	M 5
2472.11.006	M 6
2472.11.008	M 8
2472.11.010	M 10
2472.11.012	M 12
2472.11.016	M 16
2472.11.020	M 20



2472.11.024
Thrust pad driver
 for 2472.01./02.

Order No	for thread
2472.11.024	M 24